INSTALLATION MANUAL

11110TR















100-240V | R111 | GU10 | 75W | IP20 | Die cast | Adjustable

Requires base 51100TR / 51200TR.







Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Do not cover the fitting.
- 3. Maintenance and installation should only be carried out by a professional electrician.

