






# INSTALLATION MANUAL

## 38118M, 38136M, 38158M


**80**  
CRI

Complete with driver / Stainless steel clips

**38118M: 15W | SMD 2835 | 230V | PC + opal PC diffuser**

**38136M: 30W | SMD 2835 | 230V | PC + opal PC diffuser**

**38158M: 40W | SMD 2835 | 230V | PC + opal PC diffuser**

**one**  
LIGHT


### Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.