


INSTALLATION MANUAL

61130

ecolight


230V | 5W | IP20 | ABS + aluminium | Dimmable | Adjustable

 4 steps CCT
 USB output
 USB charging socket
 Wireless charger


<p>A</p> <p>Wireless charging indicator</p> <p>Wireless charging area</p> <p>Power ON/OFF</p> <p>Colour temperature</p> <p>Brightness decrease</p> <p>2 Hour poweroff</p> <p>1 Hour poweroff</p> <p>Brightness increase</p>	<p>B</p> <p>WIRELESS CHARGING APPLICABLE DEVICES:</p> <ol style="list-style-type: none"> 1. Devices with built-in wireless charging receiver. 2. Devices with reserved wireless charging interface beside its battery. 3. Devices with wireless charging receiver in its protection case.
<p>C</p> <p>When using the wireless charging function, place phones with Qi receiver onto the wireless charging area. At this time, the wireless charging indicator turns on and flicker to indicate that wireless charging works properly. The indicator turns off after the phone is removed.</p>	<p>D</p> <p>To charge a digital device, use a piece of charging cable to connect the USB output port of desk lamp with the charging port of the device.</p>

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.