


# INSTALLATION MANUAL

## 67492P Sensor

**ecolight**



**one**  
LIGHT

230V | SMD 2835 | 12W | IP54 | Sensor | Plastic + PC

Complete with 300mA driver.

80 CRI

**A**

**B**

**C**

**D**

**E**

Sensitivity Configuration and Time delay

ON

ON						
5sec	30sec	1min	3min	5min	8min	

\*SENSITIVITY      Time Delay

\* OFF High sensitivity ON Low sensitivity  
Move switch to ON position to adjust time delay.

**F**

### Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.